RV Awning Waterproofer

Waterproofs & Protects fabrics!

Also great for:

- Outdoor Furniture
- Pop-Up Campers
- RV Covers
- Tents

Directions: Clean fabric first with Full Timer's Choice Awning Cleaner (#41022) to remove all dirt and mildew. Rinse twice thoroughly to be sure to remove all detergents. RV Awning Waterproofer is most effective on clean, dry material. Shake well. Spray evenly until fabric has a "wet" look - material does not need to be saturated. Allow to dry 6-12 hours for maximum effectiveness. Use RV Awning Waterproofer seasonally or after each cleaning.

DANGER: COMBUSTIBLE. Keep out of reach of children. May cause eye irritation. For prolonged exposure, wear rubber gloves. Safe if used as directed. **First Aid: Eyes:** Flush with water for 15 minutes. CONTACT PHYSICIAN. **Skin:** Wash with soap and water. If irritation persists CONTACT PHYSICIAN. **Ingestion:** Drink large amounts of water. Do not induce vomiting. CONTACT PHYSICIAN. Do not induce vomiting or give anything by mouth to an unconscious person.

Contains: Petroleum distillates and fluoropolymer.

Our chemicals are tested extensively for the purposes noted; however, it is impossible to test compatibility for all surfaces. Test an inconspicuous area in each color to ensure compatibility. We limit responsibility of this product to a refund of the purchase price.



Camco Manufacturing, Inc.

1-800-334-2004 / www.camco.net 121 Landmark Drive / Greensboro, NC 27409 z882165 #1207